




Casing



CC225
2 ¼ x ¾




MP225
2 ¼ x ¾




FC225
2 ¼ x ¾




RW225
2 ¼ x ¾




TD225
2 ¼ x ¾




JW250
2 ½ x ¾




NFC225
2 ¼ x ¾



CC250
2 ½ x ¾




CP225
2 ¼ x ¾



OR250
2 ½ x ¾


Casing




NH275
 $2\frac{3}{4} \times \frac{3}{4}$




SC275
 $2\frac{3}{4} \times \frac{3}{4}$



RR262
 $2\frac{5}{8} \times \frac{3}{4}$



WT275
 $2\frac{3}{4} \times \frac{3}{4}$




DW262
 $2\frac{5}{8} \times \frac{3}{4}$




RM275
 $2\frac{3}{4} \times \frac{3}{4}$




RW275
 $2\frac{3}{4} \times \frac{3}{4}$



NFC275
 $2\frac{3}{4} \times \frac{3}{4}$




EW262
 $2\frac{5}{8} \times \frac{3}{4}$




CB275
 $2\frac{3}{4} \times \frac{3}{4}$


Casing




CC275
2 ¾ x ¾




DC300
3 x ¾



FC275
2 ¾ x ¾




4BC300
3 x ¾



HC275
2 ¾ x ¾




BC300
3 x ¾




FIC300
3 x ¾



1BC300
3 x ¾




NFC300
3 x ¾




SN300
3 x ¾


Casing




HC300
3 x ¾




EM325
3 ¼ x ¾




WT300
3 x ¾




RR325
3 ¼ x ¾




LG300
3 x ¾




SN338
3 ⅜ x ¾




CL312
3 ⅛ x ¾



4BC338
3 ⅜ x ¾




CH312
3 ⅛ x ¾




FIC338
3 ⅜ x ¾


Casing




DC338
 $3 \frac{3}{8} \times \frac{3}{4}$




FIC350
 $3 \frac{1}{2} \times \frac{3}{4}$




BD338
 $3 \frac{3}{8} \times \frac{3}{4}$




CH350
 $3 \frac{1}{2} \times \frac{3}{4}$




RC350
 $3 \frac{1}{2} \times \frac{3}{4}$



FC350
 $3 \frac{1}{2} \times \frac{3}{4}$




GMC350
 $3 \frac{1}{2} \times \frac{3}{4}$



MW350
 $3 \frac{1}{2} \times \frac{3}{4}$




2ER350
 $3 \frac{1}{2} \times \frac{3}{4}$




CC350
 $3 \frac{1}{2} \times \frac{3}{4}$


Casing




OD350
 $3 \frac{1}{2} \times \frac{3}{4}$




SR350
 $3 \frac{1}{2} \times \frac{3}{4}$



ON350
 $3 \frac{1}{2} \times \frac{3}{4}$




DJ343
 $3 \frac{7}{16} \times \frac{3}{4}$




MH350
 $3 \frac{1}{2} \times \frac{3}{4}$




BE350
 $3 \frac{1}{2} \times \frac{3}{4}$




DB350
 $3 \frac{1}{2} \times \frac{3}{4}$



FC356
 $3 \frac{9}{16} \times 1 \frac{1}{16}$




RM350
 $3 \frac{1}{2} \times \frac{3}{4}$




NFC375
 $3 \frac{3}{4} \times \frac{3}{4}$


Casing




MH250
2 ½ x ¾




CH275
2 ¾ x ¾




EF350
3 ½ x ¾




KW350
3 ½ x ¾



WB350
3 ½ x ¾




WB425
4 ¼ x ¾




CH525
5 ¼ x ¾


Casing




BD375
 $3 \frac{3}{4} \times 3 \frac{3}{4}$




JW375
 $3 \frac{3}{4} \times 3 \frac{3}{4}$



JL375
 $3 \frac{3}{4} \times 1 \frac{1}{4}$




MS400
 4×1




DB400
 $4 \times \frac{3}{4}$


Casing




FC425
 $4 \frac{1}{4} \times 1 \frac{1}{16}$



YK425
 $4 \frac{1}{4} \times 1 \frac{1}{16}$



KR425
 $4 \frac{1}{4} \times 1 \frac{3}{16}$




MD425
 $4 \frac{1}{4} \times 1 \frac{3}{16}$




JSC425
 $4 \frac{1}{4} \times 1$

Casing




JH387
 $3 \frac{7}{8} \times 1$




MW425
 $4 \frac{1}{4} \times \frac{3}{4}$



LN450
 $4 \frac{1}{2} \times \frac{7}{8}$




RR450
 $4 \frac{1}{2} \times \frac{3}{4}$




DR525
 $5 \frac{1}{4} \times \frac{13}{16}$


Baseboard




HL325
 $3\frac{1}{4} \times 1\frac{11}{16}$




GM325
 $3\frac{1}{4} \times 1\frac{11}{16}$



AB325
 $3\frac{1}{4} \times 1\frac{11}{16}$




BE325
 $3\frac{1}{4} \times 1\frac{11}{16}$




RE325
 $3\frac{1}{4} \times 1\frac{11}{16}$




BB325
 $3\frac{1}{4} \times 1\frac{11}{16}$



HL425
 $4\frac{1}{4} \times 1\frac{11}{16}$




GM425
 $4\frac{1}{4} \times 1\frac{11}{16}$




AB425
 $4\frac{1}{4} \times 1\frac{11}{16}$



BE425
 $4\frac{1}{4} \times 1\frac{11}{16}$




RE425
 $4\frac{1}{4} \times 1\frac{11}{16}$




BB425
 $4\frac{1}{4} \times 1\frac{11}{16}$


Baseboard




OG325
 $3\frac{1}{4} \times \frac{11}{16}$




PG325
 $3\frac{1}{4} \times \frac{11}{16}$




CB325
 $3\frac{1}{4} \times \frac{11}{16}$




TD325
 $3\frac{1}{4} \times \frac{11}{16}$




OR325
 $3\frac{1}{4} \times \frac{11}{16}$




EW325
 $3\frac{1}{4} \times \frac{11}{16}$




OG425
 $4\frac{1}{4} \times \frac{11}{16}$




PG425
 $4\frac{1}{4} \times \frac{11}{16}$



CB425
 $4\frac{1}{4} \times \frac{11}{16}$



TD425
 $4\frac{1}{4} \times \frac{11}{16}$




OR425
 $4\frac{1}{4} \times \frac{11}{16}$




EW425
 $4\frac{1}{4} \times \frac{11}{16}$


Baseboard



HL525
5¼ X 11/16




GM525
5¼ X 11/16




AB525
5¼ X 11/16



BE525
5¼ X 11/16




RE525
5¼ X 11/16




BB525
5¼ X 11/16


Baseboard




OG525
5¼ X 11/16




PG525
5¼ X 11/16




CB525
5¼ X 11/16



OR525
5¼ X 11/16




EW525
5¼ X 11/16



GR525
5¼ X 11/16

Baseboard



JS425
4¼ X 11/16

EB425
4¼ X 11/16



WT425
4¼ X 11/16

JS525
5¼ X 11/16


EB525
5¼ X 11/16

WT525
5¼ X 11/16


Crown




Crown




CM175
 $1\frac{3}{4} \times \frac{1}{2}$




CM225
 $2\frac{1}{4} \times 1\frac{11}{16}$



CM275
 $2\frac{3}{4} \times \frac{3}{4}$




CM325
 $3\frac{1}{4} \times 1\frac{13}{16}$




CM425
 $4\frac{1}{4} \times \frac{3}{4}$


Crown




Crown




Crown




Crown




SCM225
 $2\frac{1}{4} \times 1\frac{3}{16}$



SCM325
 $3\frac{1}{4} \times 1\frac{3}{16}$




SCM425
 $4\frac{1}{4} \times 1\frac{3}{16}$




SCM525
 $5\frac{1}{4} \times 1\frac{3}{16}$


Crown




LCM325
3 1/4 x 1




GCM325
3 1/4 x 7/8




GCM425
4 1/4 x 7/8




OCM275
2 3/4 x 3/4




LCM175
1 3/4 x 9/16




NFC150



ICM275
2 3/4 x 3/4




ICM300
3 x 5/8




YCM325
3 1/4 x 1 1/16


Crown




2BC325
3 1/4 x





2BC525
5 1/4 x 13/16



2BC425
4 1/4 x 13/16




2BC338
3 3/8 x 3/4




CRCM375
3 3/4 x 3/4




WCM350
3 1/2 x 13/16




Crown




HCM425
4 1/4 x 3/4




ECM425
4 1/4 x 13/16



RCM425
4 1/4 x 3/4




JCM425
4 1/4 x 3/4




JCM250
2 1/2 x 3/4


Crown




MCM525
 $5\frac{1}{4} \times 1\frac{13}{16}$



KCM525
 $5\frac{1}{4} \times \frac{3}{4}$




ICM450
 $4\frac{1}{2} \times 1\frac{13}{16}$




ACM425
 $4\frac{1}{4} \times \frac{7}{8}$

Crown




VCM425
 $4\frac{1}{4} \times 1\frac{3}{16}$





VCM750
 $7\frac{1}{2} \times 1\frac{5}{16}$

Crown



SI462
 $4\frac{5}{8} \times 1\frac{1}{16}$




CRCM850
 $8\frac{1}{2} \times 1\frac{1}{4}$


Chair Rail




CR250
2½ x 5⁄8




CR275
2¾ x ¾




BCR275
2¾ x ¾




CR325
3¼ x ¾




CR331
3⁵/₁₆ x 5⁄8



CR350
3½ x ¾




CR475
4¾ x ¾




CR500
5 x 1



CR512
5½ x 1¾




DCR325
3¼ x ¾



CR225
2¼ x ¾


Tongue Vee Groves and Furniture Base



6" Double Bead




3" Single Bead



3" Double Bead



3" V-Groove




FB338
3 $\frac{3}{8}$ x 1



FB400
4 x 1




FB438
4 $\frac{3}{8}$ x 1




FB550
5 $\frac{1}{2}$ x 1

Bar Rail


3" Bar Rail



4½" Bar Rail



6½" Bar Rail




Small Mouldings




CL75
 $\frac{3}{8} \times \frac{1}{2}$




CL50
 $\frac{1}{2} \times \frac{1}{4}$




B62
 $\frac{5}{8} \times \frac{1}{4}$




B75
 $\frac{3}{4} \times \frac{5}{16}$




L75
 $\frac{3}{4} \times \frac{3}{8}$



GC100
 $1 \times \frac{7}{16}$




GC401
 $\frac{3}{4} \times \frac{1}{2}$




J75
 $\frac{3}{4} \times \frac{1}{2}$



P75
 $\frac{3}{4} \times \frac{1}{4}$




P125
 $1\frac{1}{4} \times \frac{1}{4}$




P225
 $2\frac{1}{4} \times \frac{1}{4}$



C75
 $\frac{3}{4} \times \frac{1}{4}$




US81
 $\frac{13}{16} \times \frac{9}{16}$




S81
 $\frac{13}{16} \times \frac{5}{16}$




S150
 $1\frac{1}{2} \times \frac{5}{16}$




JW106
 $1\frac{1}{16} \times \frac{7}{16}$



D100
 $1 \times \frac{1}{2}$




DM112
 $1\frac{1}{8} \times \frac{9}{16}$




DM50
 $\frac{3}{4} \times \frac{1}{2}$


Small Mouldings




CM50
1/2 x 1/2




CM75
3/4 x 3/4




CM100
1 x 1




CM125
1 1/4 x 1 1/4




CM150
1 1/2 x 1 1/2




R81
13/16 x 5/8




T100
15/16 x 3/4




OC75
3/4 x 3/4




OC125
1 1/4 x 1 1/4




H138
1 3/8 x 1




M300
11/16 x 3/4




M400
13/16 x 3/4




M500
3/4 x 3/4




M600
13/16 x 3/4




M700
1 1/8 x 3/4




SM50
1/2 x 3/4



QR75
3/4 x 3/4




QR100
1 x 1




BC75
3/4 x 3/4


Small Mouldings




MY112
1 1/8 x 3/4




CG112
1 1/8 x 3/4




MH150
1 1/2 x 13/16




Q100
1 x 1/2




PMGC100
15/16 x 5/8




PMGC125
1 3/8 x 3/4




PMGC112
1 3/8 x 3/4




OS125
1 1/4 x 3/4



PK303
1 1/16 x 11/16




PM138
1 3/8 x 3/4




JSC118
1 3/16 x 5/8




EBC138
1 3/8 x 5/8




CBC150
1 1/2 x 5/8




Y100
1 x 1/2



W68
11/16 x 3/8




RT1
1 x 5/8




RTS225
2 1/4 x 5/8


Small Mouldings




SZ138
 $1\frac{3}{8} \times \frac{3}{4}$




T162
 $1\frac{5}{8} \times \frac{5}{8}$




OS162
 $1\frac{5}{8} \times \frac{13}{16}$




GD138
 $1\frac{3}{8} \times \frac{3}{4}$




PM125
 $1\frac{1}{4} \times \frac{5}{8}$




MD138
 $1\frac{3}{8} \times \frac{9}{16}$



OS188
 $1\frac{7}{8} \times \frac{3}{4}$



J125
 $1\frac{1}{4} \times \frac{5}{8}$




MD125
 $1\frac{1}{4} \times \frac{5}{8}$




DS138
 $1\frac{3}{8} \times \frac{7}{16}$




SDS138
 $1\frac{3}{8} \times \frac{1}{2}$




BDS138
 $1\frac{3}{8} \times \frac{1}{2}$



GC138
 $1\frac{3}{8} \times 1\frac{1}{8}$




CG138
 $1\frac{3}{8} \times 1\frac{1}{8}$




FT175
 $1\frac{3}{4} \times 1\frac{1}{4}$


Small Mouldings




RC150
1½ x ¾




FC150
1½ x ¾




HR200
2 x 7⁄8




RC287
2⁷⁄₈ x ¾




RC212
2¹⁄₈ x ¾




HR50
½ x ¼




HR75
¾ x ⅜




TD150
1½ x ½




HL125
1¼ x ¾




WS218
2³⁄₁₆ x 1¼




CG188
1⁷⁄₈ x 1⁵⁄₁₆




P404
¾ x 9⁄₁₆



PM200
2 x ¾




RK200
2 x ¾




KR200
2 x 1¹⁄₁₆


Small Mouldings




P101
1 1/16 X 1/2




P202
7/8 X 11/16




P303
7/8 X 5/8




P505
1 1/8 X 7/8



P606
1 1/2 X 13/16




MM150
1 1/2 X 5/8




P707
1 1/8 X 9/16




IC300
3 X 1 1/2




GA338
3 3/8 X 1 1/2




GA188
1 7/8 X 1 3/4




PM200 R5
2 X 1 1/16




AM106
1 1/16 X 1 1/8



AR125
1 1/4 X 1 1/4




AM125
1 1/4 X 1




AR138
1 3/8 X 1 1/16


Small Mouldings




VC162
1 5/8 x 1 1/16




VC138
1 3/8 x 15/16




VC144
1 7/16 x 1 5/16




VC137
1 3/8 x 3/4




VC150
1 1/2 x 1 5/16




VC175
1 3/4 x 7/8




SO325
3 1/4 x 7/8




SO300
3 x 1 1/16




JK225
2 1/4 x 1 1/16




R100
1 x 5/16




OS175
1 3/4 x 13/16



JL225
2 1/4 x 3/4




RC162
1 5/8 x 1/2




DW200
2 x 3/4


Jambs and Accessories




Reeded Jamb




Fluted Jamb




Flat Jamb



Exterior Jamb




Brick Mould
2 x 1 $\frac{1}{4}$




T-Astrigal
1 $\frac{3}{4}$ x 1 $\frac{3}{4}$

Blocks


Call for available sizes of all blocks shown on this page.




R2 Rosette




R1 Rosette



**Corner Base Block
CB2 Block**




**Corner Base Block
CB1 Block**




Plinth Block


Crown







Crown




Crown



Crown



Crown




WCM450
 $4\frac{1}{2} \times \frac{7}{8}$



TCM425
 $4\frac{1}{4} \times \frac{7}{8}$




IU438
 $4\frac{3}{8} \times 1$




SWCM412
 $4\frac{1}{8} \times \frac{7}{8}$


Crown




Small Moldings




GC250
2½ x 1½




WH112
1½ x 1³⁄₁₆




MVC175
1¾ x 1½




ON125
1¹⁵⁄₁₆ x 1




KLW181
1¹³⁄₁₆ x 1½




GCVC175
1¾ x 1




PM250
2½ x ¾




HV112-138
1⁵⁄₁₆ x 1³⁄₈




GC10187
1⅞ x 1



HV175-212
1¾ x 2




HV125-200
1¼ x 2




BEVC162
1³⁄₁₆ x 1½


Small Moldings




GR137
1 3/8 X 3/4




GR707-M
1 3/16 X 9/16




GR707
1 1/8 X 5/8




GR606
1 7/16 X 3/4




GR.81 BC
7/8 X 5/16




GR505
1 3/16 X 3/4




GR303
7/8 X 3/4




GR65
5/8 X 5/8




GR125
1 3/16 X 11/16



GR404
3/4 X 5/8




GR50
1/2 X 3/8




GR100
1 1/16 X 5/8


Small Moldings




P202 AKA AM102
 $\frac{7}{8} \times \frac{3}{4}$



CL.81 AM
 $1\frac{3}{16} \times 1$




P101 AKA AM105
 $\frac{5}{8} \times \frac{9}{16}$




CL.62 AM
 $\frac{5}{8} \times \frac{7}{8}$




AM124
 $\frac{5}{16} \times \frac{3}{8}$



CL.2562 AM
 $\frac{1}{4} \times \frac{3}{4}$




Wyatt. 37
 $\frac{3}{8} \times \frac{1}{2}$




CL.25
 $\frac{1}{4} \times \frac{1}{2}$


Small Moldings




WK175
 $\frac{5}{8} \times 1\frac{3}{4}$




IC225
 $\frac{5}{8} \times 2\frac{1}{4}$




HVC150
 $\frac{3}{4} \times 1\frac{1}{2}$




TY75
 $\frac{3}{4} \times \frac{3}{8}$




WR300
 $3 \times \frac{7}{8}$




MW75
 $\frac{3}{8} \times \frac{3}{4}$




MH103
 $1\frac{1}{16} \times \frac{9}{16}$




PMGC131
 $\frac{5}{16} \times \frac{5}{8}$




MH138
 $1\frac{3}{8} \times 1\frac{13}{16}$




MY75
 $\frac{1}{2} \times \frac{3}{4}$




HR175
 $1\frac{3}{4} \times 1\frac{13}{16}$



HR150
 $1\frac{1}{2} \times \frac{3}{4}$




HR112
 $1\frac{1}{8} \times \frac{9}{16}$




D75
 $\frac{1}{2} \times \frac{3}{4}$


Small Moldings




GR.8111
5/8 X 7/8




BRVC164
13/16 X 1 5/8




MH162
7/8 X 1 5/8




MB1625
3/4 X 1 5/8




GR187
7/8 X 1




SW100-81
1 X 13/16




SW100
1 X 1



CW150
1 3/16 X 1 1/2




GR187-T
1/4 X 1




GC106
5/8 X 1 1/16




GR2583
1/4 X 3 1/2



GT100-62
1/4 X 1




GR3562
1/4 X 13/16




TG100-50
1/2 X 1




GR2583-AM
1/4 X 7/8




GY125
1 1/4 X 7/8



RL138
1 X 1 3/8




GC10150
1 X 1 1/2




GC34175
3/4 X 1 3/4

Ship-Lap




4 $\frac{1}{4}$ " cover
 $\frac{3}{4}$ " x 4 $\frac{3}{4}$ " overall

Chair Rail




CR300
 $\frac{5}{8} \times 3$



BCR200
 $\frac{3}{4} \times 2$


Casing




NHT325
 $\frac{3}{4} \times 3\frac{1}{4}$




EM375
 $\frac{3}{4} \times 3\frac{3}{4}$




NHT300
 $\frac{3}{4} \times 3$




DCB350
 $1\frac{1}{16} \times 3\frac{1}{2}$




CC300
 $\frac{3}{4} \times 3$




EF275
 $\frac{3}{4} \times 2\frac{3}{4}$



AH350
 $1\frac{1}{16} \times 3\frac{1}{2}$




KR275
 $\frac{3}{4} \times 2\frac{3}{4}$




EF425
 $\frac{3}{4} \times 4\frac{1}{4}$

Casing




NE4-350
 $\frac{3}{4} \times 3\frac{1}{2}$




KL350
 $\frac{3}{4} \times 3\frac{1}{2}$



WE300
 $\frac{3}{4} \times 3$




JSC400
 $\frac{13}{16} \times 4$



CC400
 $\frac{3}{4} \times 4$




NHV462
 $\frac{3}{4} \times 4\frac{5}{8}$




CC475
 $\frac{3}{4} \times 4\frac{3}{4}$


Casing




JH387
 $\frac{3}{4} \times 3\frac{7}{8}$




JM225
 $\frac{3}{4} \times 2\frac{1}{4}$




DB400
 $\frac{3}{4} \times 4$




RSC300
 $\frac{3}{4} \times 3$




NFC425
 $\frac{5}{8} \times 4\frac{1}{4}$



SA500
 $\frac{13}{16} \times 5$




MC512
 $\frac{3}{4} \times 5\frac{1}{8}$




RWC525
 $\frac{3}{4} \times 5\frac{1}{4}$

Casing



SC350

$\frac{3}{4} \times 3\frac{1}{2}$




JSC325

$\frac{3}{4} \times 3\frac{1}{4}$



GJ343


$\frac{3}{4} \times 3\frac{7}{16}$




DB400

$\frac{3}{4} \times 4$


Baseboard




WF525
 $\frac{9}{16} \times 5\frac{1}{4}$




JL525
 $\frac{9}{16} \times 5\frac{1}{4}$



JBL500
 $\frac{3}{4} \times 5$




KK525
 $\frac{3}{4} \times 5\frac{1}{4}$



KK425
 $\frac{3}{4} \times 4\frac{1}{4}$

Baseboard



CLB450

$1\frac{1}{16} \times 4\frac{1}{2}$

WPG475

$\frac{3}{4} \times 4\frac{3}{4}$

GCB450

$\frac{3}{4} \times 4\frac{1}{2}$


ABF425

$\frac{3}{4} \times 4\frac{1}{4}$


RSB425

$1\frac{1}{16} \times 4\frac{1}{4}$


Baseboard




EMB400
 $1\frac{1}{16} \times 4$




AFB400
 $\frac{3}{4} \times 4$




KK325
 $\frac{3}{4} \times 3\frac{1}{4}$




TA425
 $\frac{5}{8} \times 4\frac{1}{4}$




PB425
 $\frac{5}{8} \times 4\frac{1}{4}$



CO425
 $1\frac{1}{16} \times 4\frac{1}{4}$




GK425
 $\frac{5}{8} \times 4\frac{1}{4}$




KL425
 $1\frac{1}{16} \times 4\frac{1}{4}$


Baseboard




GCB275
 $\frac{3}{4} \times 2\frac{3}{4}$




DM525
 $\frac{5}{8} \times 5\frac{1}{4}$




WHB525
 $1\frac{1}{16} \times 5\frac{1}{4}$



MHWB525
 $1\frac{1}{16} \times 5\frac{1}{4}$



RSB525
 $1\frac{1}{16} \times 5\frac{1}{4}$



RJS525
 $1 \times 5\frac{1}{4}$